


I N S T E  N[®]



Insteon Hub
Owner's Manual

Contents

Getting Started

Insteon Hub	4
Device Overview	4
Installation	4
Download the App	4
Create an Account	4

Insteon App

Insteon App on iOS	6
Insteon App on Android	11
Insteon App on Windows	16

Insteon Connects

Hardware Reset

Diagnostics	23
Network Reset	24
Factory Reset	25

Appendix


Specifications	28
Troubleshooting	30
Certifications and Warnings	33
Declaration of Conformity	34
Product Warranty	35

Getting Started

Everything you need to quickly get up and running.


Insteon Hub

Device Overview




Installation

Connect your Hub to the internet and a power outlet using the cables provided. Avoid switched outlets or filtered power strips.




Download the App

From your mobile device, download and install **Insteon for Hub** from your device's app store.



Create an Account

Launch the App and follow the on-screen instructions to create an account and setup the Insteon Hub.




✓ You're done setting up your Insteon Hub; now start adding devices.

Insteon App

Use the Insteon App to configure and control your Insteon Hub. Everything from adding a device to controlling your thermostat is handled through the app.


Insteon App on iOS



The Insteon app on iOS uses a right-hand drawer to navigate between Check-In, Favorites, Rooms, Scenes, Thermostats and Settings. You can also add and edit devices, rooms and scenes from the drawer.


Check-In

An at-a-glance overview of all of your Insteon sensors. Sensors are white when red when triggered and white when not.



Favorites


A customizable screen where you can place your most used devices, scenes and sensors.



Insteon App on iOS


Rooms

Lets you group devices into rooms for easier navigation.




Scenes

Automatically displays all of the scenes that have been created.




Thermostat

Displays your Insteon or Nest Thermostat. For homes with multiple thermostats, you can configure the default from settings.





Settings

Your one-stop-shop for Hub and Insteon account settings and configuration. You can also find in-app help here.



Insteon App on iOS

Controlling a Device




Tap to turn the device on or off



Tap for additional control and to edit the device.

Additional Device Control



— Tap On

— Tap Off

Turn a device on or off, regardless of brightness




Quickly adjust the brightness



Tap the arrows to adjust in 10%-ish increments

Insteon App on iOS

Monitoring a Sensor



Indicates that your sensor is not triggered





Indicates that your sensor has been triggered



Indicates that the Hub has lost contact with your sensor

If a newly added sensor shows yellow, try activating it.


Controlling a Camera



Tap the arrows to pan and tilt your camera

Insteon App on iOS

Controlling a Scene




Tap to turn the scene on or off




Tap for additional control and to edit the scene.

Additional Scene Control



Tap to turn the scene on or off


Insteon App on Android



The Insteon app on Android uses tabs to navigate between Check-In, Favorites, Rooms, Scenes, Thermostats and Settings. You can add and edit devices, rooms and scenes from the settings button.


Check-In

An at-a-glance overview of all of your Insteon sensors. Sensors are red when triggered and white when not.



Favorites


A customizable screen where you can place your most used devices, scenes and sensors.



Insteon App on Android


Rooms

Lets you group devices into rooms for easier navigation. Also the location for **All Devices** which displays every device added to your house




Scenes

Automatically displays all of the scenes that have been created.




Thermostat

Displays your Insteon or Nest Thermostat. For homes with multiple thermostats, you can configure the default from settings.





Settings

Your one-stop-shop for Hub and Insteon account settings and configuration. You can also find in-app help here.



Insteon App on Android

Controlling a Device




Tap to turn the device on or off



Tap for additional control and to edit the device.

Additional Device Control



— Tap On

— Tap Off

Turn a device on or off, regardless of brightness




Quickly adjust the brightness



Tap the arrows to adjust in 10%-ish increments

Insteon App on Android

Monitoring a Sensor



Indicates that your sensor is not triggered




Indicates that your sensor has been triggered



Indicates that the Hub has lost contact with your sensor

If a newly added sensor shows yellow, try activating it.

Controlling a Camera



Use the arrows to pan and tilt your camera

Insteon App on Android

Controlling a Scene




Tap to turn the scene on or off



Tap for additional control and to edit the scene.


Additional Scene Control



Tap to turn the scene on or off


Insteon App on Windows

The Insteon app on Windows Phone uses a six-screen carousel to switch between Quick View, Favorites, Rooms, Scenes, Thermostats and Settings.




Quick View

An at-a-glance overview of all of your Insteon sensors. Sensors are green when closed and red when triggered.



Favorites

A customizable screen where you can place your most used devices, scenes and sensors.



Insteon App on Windows


Rooms

Lets you group devices into rooms. Also the location for **All Devices** which displays every device added to your house.




Scenes

Automatically displays all of the scenes that have been created.




Thermostats

Displays your Insteon Thermostat. For homes with multiple thermostats, you can configure the default from settings.





Settings

Your one-stop-shop for Hub and Insteon account settings and configuration. You can also find in-app help here.



Insteon App on Windows

Controlling a Device



Tap the arrows to adjust in 10% increments





Slide to quickly adjust the brightness




Turn a device on or off, regardless of brightness


Monitoring a Sensor



Indicates that your sensor is OK



Indicates that your sensor has been triggered




Indicates that the Hub has lost contact with your sensor

If a newly added sensor shows yellow, try activating it.

Insteon App on Windows

Controlling a Scene




Tap to turn the scene on or off



Tap to edit the scene

Controlling a Camera



Use the arrows to pan and tilt your camera

Insteon Connects

We've partnered with some of the leading accessory manufacturers and platforms to bring you the best possible connected home experience.



Hi, I'm Cortana.

Insteon Connects

We know that the smart home of tomorrow will be full of products from many manufacturers; customers are going to choose the right product for the right niche. Insteon fully embraces the platform agnostic IoT.

[Learn more at insteon.com/connects](http://insteon.com/connects)

logitech

SONOS



stringify


Hardware Reset

A network reset will restore the default network configuration to the Hub.
A factory reset will erase all links stored in the device's database as well as any customized properties.

Diagnostics

You can enter an audio diagnostic mode that will report a connection issue in seven potential areas. Once in the diagnostic mode, your Hub will beep through a series of tests.

- 1 Tap the set button twice, wait one second and then tap the set button again once.



 Single Beep: Test Passed

 Double-Beep: Test Failed

Test 1

Insteon Hub Modem active

Test 2

Internet Time Server reachable

Test 3

Hub has a valid IP Address

Test 4

Connected to Insteon Servers

Test 5

Active remote connection to
Insteon's Servers

Test 6


Successful remote connection
to Insteon's Servers at power up

Test 7


Successful connection to real-time
messaging service

Network Reset

- 1 Tap the set button three times. The Hub will triple-beep.



- 2 After a few seconds the Hub will single-beep.




✓ Your Hub has been restored to default network settings.


Factory Reset

- 1 Prior to performing a factory reset, you must delete all devices and scenes or factory reset all of your devices and delete your user account from Insteon.


Navigate to settings



- 2 From Settings, tap Account



- 3 Tap Delete Account. **This cannot be undone and will erase your home from Insteon Connect.**




- 4 Disconnect power from the Hub




Factory Reset


- 5 Press and hold the set button while reconnecting power. The Hub will emit a long beep.



- 6 When the long beep ends, release the set button. The Hub will double-beep. After 30 seconds, your Hub will beep again.



- 7 Unplug and then reconnect your Hub to power.



✓ Your Hub has been restored to factory settings.

Appendix

Everything else you might need to know about your Insteon product.

Specifications

General

Available Colors	White
Brand:	Insteon
Manufacturer Product No.:	2245-422
Patent No.:	Protected under US and Foreign Patents (see www.insteon.com/patents)
UPC:	813922013498
Warranty:	2 years, limited

Operation

Setup Memory	Non-volatile EEPROM
Status LED	Red/Green LED

Insteon Features

Insteon Device Category	0x03
Insteon Device Subcategory	0x35
Insteon ID	1
Insteon Links	3992
Insteon Messages Repeated	Yes
Insteon Minimum Receive Level	40 mV
Insteon Minimum Transmit Level	3.2 Vpp into 5 Ohms
Insteon Powerline Device	Yes
Insteon Powerline Frequency	131.65 KHz
Insteon RF Device	Yes
Maximum Controlled Scenes	256
Maximum Scene Memberships	3992

Multi-Link Support	Yes
Multi-Unlink Support	Yes
RF Beacon	Yes
Radio Frequency	869.85 MHz
Radio Frequency Range	Up to 250 feet (76 meters)

Mechanical

Beep on Button Press	No
Dimensions	7.1" H x 4.1" W x 1.25" H 18.2 cm H x 10.4 cm W x 3.2 cm D
Enclosure Material	UV stabilized plastic
Mounting	Tabletop or Wall Mount
Operating Environment	Indoors
Operating Humidity Range	0-90% relative humidity
Operating Temperature Range	32° to 104° F 0° to 40° C
Factory Reset Button	Yes
Storage Temperature Range	-4° to 158° F -20° to 70° C
Weight	5.2 oz

Electrical

Power Consumption	3 Watts
Supply Voltage	100-240V, 50/60Hz, single phase
Surge Resistance	Surges over 1000 volts
Power Connector	IEC C8
Certification	IEC 62368-1:2014 (Second Edition) CB Scheme Certificate #US/6345/ITS ETSI EN 301 489-3 V1.6.1 (Testing in March 2016) ETSI EN 300 220-2 V2.4.1 (Testing in March 2016)

Troubleshooting

Initial Setup and Configuration

Unable to create an Insteon account

There is most likely an internet connection issue between your mobile device and the Insteon Hub

Try this:

- Make sure your internet connection is working by trying to browse a website on your mobile device
- Look for any typos in your email address that might prevent the account from creating; if you are missing the “@” symbol or “.com,” add them. Insteon requires a full, valid email address.

Insteon App is unable to find your Insteon Hub

A number of factors can impact the initial setup but most of them are internet connection related.

Try this:

- Check all of the cables going into the Hub and make sure they are firmly seated. Trace the ethernet cable from the Hub back to the router and make sure it is connected properly there, too.
- Look for signs of life from the Insteon Hub. Even if not properly connected, you should see a green LED glow on the front of the Hub. If the LED doesn't illuminate, check the power outlet. There should also be a blinking green and solid orange light on the Hub's ethernet port. If both ethernet LEDs are off, try a different port on your router.
- Try power cycling your Hub by unplugging and then reconnecting it to power.
- For the initial connection, your mobile device must be connected to the WiFi network being generated by the same router to which the Hub is connected. While some routers create a “guest” network, you most often need to be connected to the main WiFi network being created by your router for the initial setup to work correctly.
- You can check to see if the Insteon Hub was able to properly “phone home” to Insteon. This will at least tell you that the Hub is up and running, even if a network configuration problem is preventing you from connecting to the Hub. On your mobile device or computer, open a browser and visit connect.insteon.com/getinfo.asp. Any detected Insteon Hubs will be displayed on this page.
- Try a network reset (see Network Reset).
- If the problem persists, contact Insteon Support 866-243-8022

Insteon App is unable to connect to your Insteon Hub

A number of factors can impede connection to the Insteon Hub but most of them are internet connection related.

Try this:

- Check all of the cables going into the Hub and make sure they are firmly seated. Trace the ethernet cable from the Hub back to the router and make sure it is connected properly there, too.
- Look for signs of life from the Insteon Hub. Even if not properly connected, you should see a green LED glow on the front of the Hub. If the LED doesn't illuminate, check the power outlet. There should also be a blinking green and solid orange light on the Hub's ethernet port. If both ethernet LEDs are off, try a different port on your router.
- Ensure that your home internet connection is functioning by visiting a website from your computer's internet browser.
- Restart your Hub by unplugging and then reconnecting it to power.

Troubleshooting

General Issues

Unable to add a new device using the Insteon App

Inability to add a new device is usually centered around issues with the Insteon network.

Try this:

- Relocate the new device closer to the Insteon Hub and try again. If this works, you may need a Range Extender or an additional Dual-Band Insteon device to increase the reach of your Insteon Network.
- Log out of the Insteon App and sign back in. From the Insteon App, navigate to Settings and tap Log Out at the bottom of the screen.

Unable to delete a device using the Insteon App

Deleting a device from the Insteon App may encounter issues if that device is no longer present or connected in your home.

Try this:

- Ensure that the device to be deleted is plugged in or otherwise powered. If it is a battery powered device, press and hold the set button until the Status LED begins blinking and then try deleting from the App.
- If the device to be deleted has stopped functioning, you can force the Insteon App to delete the device but only after attempts to delete the device are unsuccessful by the app. You will be presented with an option to Force Remove the unresponsive device.
- Log out of the Insteon App and sign back in. From the Insteon App, navigate to Settings and tap Log Out at the bottom of the screen.

Unable to add a new WiFi Camera using the Insteon App

There are several points to check when a WiFi Camera cannot be added using the Insteon App.

Try this:

- Ensure that your router is functioning properly and that the Ethernet cable connecting the WiFi Camera is firmly connected to both the camera and your router.
- Confirm that the WiFi camera has power.
- Log out of the Insteon App and sign back in. From the Insteon App, navigate to Settings and tap Log Out at the bottom of the screen.

Unable to receive alerts via email

The Insteon Connect cloud service may require updating if an alert setting was not properly saved.

Try this:

- Check your email for a message from Insteon Connect. After initially configuring alerts, a confirmation link needs to be clicked to confirm that you wish to enable alerts for the specified email address. This email may have been inadvertently routed to your spam folder or deleted.

Troubleshooting

General Issues

- Disable and then re-enable alerts for the device that is not transmitting alerts.
- Ensure that a recipient email address is entered for the alert.
- Ensure that the Insteon for Hub app has permission to send push notifications. From the home screen of your iPhone, iPad or iPod touch, navigate to Settings. Scroll to the bottom of the list and locate Insteon. In the “Allow Insteon to Access” section, tap Notifications. Flip the switch to green to enable push notifications. You will still need to configure push notifications on a per-device basis from within the Insteon app.

Unable to disable alerts via email

The Insteon Connect cloud service may require updating if an alert setting was not properly saved.

Try this:

- Log out of the Insteon App and sign back in.
- Delete the device for which alerts cannot be disabled and then re-add the device and enable alerts.

Schedules do not appear to run at the correct time

It is possible that the Hub’s clock is incorrect and requires resetting.

Try this:

- From the Insteon App, navigate to Settings > House and check Hub Local Time. If this time is incorrect or if the Hub Location is incorrect, tap Hub Location and locate your Insteon Hub on the map. This will automatically update your Hub’s internal clock.
- If updating the Hub time does not correct the schedule run time, try a Network Reset.

Check for firmware updates for your Insteon Hub

Your Hub will update its firmware automatically but you can manually check for updates.

Try this:

- From the Insteon App, navigate to Settings > House and tap Check for Updates.

Certifications and Warnings

Read and understand these instructions before installing and retain them for future reference.

This product is not designed or approved for use on powerlines other than 100-240VAC, 50Hz or 60Hz, single phase. Attempting to use this product on unapproved powerlines may have hazardous consequences.

- Use only indoors or in outdoor rated box
- This product may feel warm during operation. The amount of heat generated is within approved limits and poses no hazards. To minimize heat buildup, ensure the area surrounding this product is as clear of clutter as possible.
- Each Insteon product is assigned a unique Insteon I.D., which is printed on the product's label.
- Changes or modifications to the hardware not expressly approved by Insteon may void the user's authority to operate the equipment in a licensed manor.
- For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.

Declaration of Conformity

I N S T E  N[®]

**EU Declaration
of Conformity**



This verification is given that:

SmartLabs, Inc.

16542 Millikan Ave., Irvine, CA 92606 United States, +1 (949) 221-0037

The following designated product(s):

Product Name(s):	Hub Interface with Euro-pin AC Cable Hub Interface with UK BS 1363 AC Cable
Trade Name:	Insteon
Model Number(s):	2245-422, 2245-442

We hereby declare, that all major safety requirements, concerning to

- CE Mark Directive (93/68/EEC)
- R&TTE Directive 1999/5/EC
 - Electromagnetic Compatibility Directives (2014/30/EU, 92/31/EEC)
- Low Voltage Directive (2014/35/EU)
- Hazardous Substance Directive- RoHS (2011/65/EU)

are fulfilled, as laid out in the guideline set down by the member states of the EEC Commission. This declaration is valid for all samples that are part of this declaration.

Complies with the essential protection requirement of European Council Directive. The Equipment was passed the test performed according to the following harmonized standards:

Harmonized Standard	Test Lab	Lab Address	Report Issued & Date
ETSI EN300 220-2 V2.4.1		110 Oinda N. Place Brea CA, 92823 United States	Report No. 97394-8 16-March-2016
ETSI EN301 489-3 V1.6.1		110 Oinda N. Place Brea CA, 92823 United States	Report No. 97394-7 15-March-2016
IEC 62368-1 (ed.2)		Intertek Testing Services, NA 25800 Commercentre Drive, Lake Forest CA 92630 United States	Report No. 102672018LAX-001 15-August-2016
		Intertek Testing Services, N.A. 165 Main Street Cortland, NY 13045 United states	Certificate US/6345/ITS 21-September-2016

The products bear the CE Mark, which was first affixed in 2017. The Technical Construction File required by the directive(s) is maintained at the corporate headquarters of SmartLabs, Inc.

Signature



Digitally signed by Dan Gregg
DN: cn=Dan Gregg, o=Insteon,
email=dgregg@insteon.com, c=US
Date: 2017.02.07 08:38:08 -08'00'

Date

7-Feb-17

Dan Gregg – Chief Technology Officer

Product Warranty

Limited Warranty

Seller warrants to the original consumer purchaser of this product that, for a period of two years from the date of purchase, this product will be free from defects in material and workmanship and will perform in substantial conformity to the description of the product in this Owner's Manual. This warranty shall not apply to defects or errors caused by misuse or neglect. If the product is found to be defective in material or workmanship, or if the product does not perform as warranted above during the warranty period, Seller will either repair it, replace it, or refund the purchase price, at its option, upon receipt of the product at the address below, postage prepaid, with proof of the date of purchase and an explanation of the defect or error. The repair, replacement, or refund that is provided for above shall be the full extent of Seller's liability with respect to this product. For repair or replacement during the warranty period, call 949-221-0037 or email support@insteon.com with the Model # and Revision # of the device to receive an RMA# and send the product, along with all other required materials to:

Insteon
ATTN: Smartlabs RMA
17421 Von Karman Ave.
Irvine, CA 92614

Limitations

The above warranty is in lieu of and Seller disclaims all other warranties, whether oral or written, express or implied, including any warranty of merchantability or fitness for a particular purpose. Any implied warranty, including any warranty of merchantability or fitness for a particular purpose, which may not be disclaimed or supplanted as provided above shall be limited to the two-year of the express warranty above. No other representation or claim of any nature by any person shall be binding upon Seller or modify the terms of the above warranty and disclaimer.

Home automation devices have the risk of failure to operate, incorrect operation, or electrical or mechanical tampering. For optimal use, manually verify the device state. Any home automation device should be viewed as a convenience, but not as a sole method for controlling your home.

In no event shall Seller be liable for special, incidental, consequential, or other damages resulting from possession or use of this device, including without limitation damage to property and, to the extent permitted by law, personal injury, even if Seller knew or should have known of the possibility of such damages. Some states do not allow limitations on how long an implied warranty lasts and/or the exclusion or limitation of damages, in which case the above limitations and/or exclusions may not apply to you. You may also have other legal rights that may vary from state to state.